



Raised Garden Bed

Installation Instructions

NOTES: Please check for any damage caused by the shipping company and take appropriate steps to file a claim, if needed.

*Please call **Digsafe** and check for any underground utilities before digging anywhere.

Materials needed

Cordless drill/driver, T25 bit, level, tape measure, spade shovel, transfer (flat) shovel, garden rake, and hand tamp.

Instructions

1. Remove items from pallet or packaging. You should find two (2) garden bed sides with 4x4 posts attached, two (2) sides with bracing attached, and one (1) package of hardware.
2. Lay out all four sides as shown in Image 1 below.
3. Attach the two sides without posts to the two sides with posts, fasten together, then remove bracing.
4. Move to desired location.

**Note:* Raised garden beds are intended to be placed directly on existing grade with no prep work needed. If you wish the garden bed to sit level, prep the area accordingly.

5. Fill with top soil and plant.
6. All wood is treated with kid-friendly preservative, but as is the case with all wood facing the elements, it needs to be cared for, so check it periodically for rough spots, splinters, etc, and sand them out, and treat it with kid-friendly wood preservative (we have it available if you can't find it) once or twice a year to keep the wood from deteriorating.
7. Enjoy your Raised Garden Bed!



Image 1



Image 2